Japan aiwa

EB-850ANC
真无线蓝牙耳机

Designed in Japan
アイワ株式会社

何为降噪

降噪是通过内置麦克风实际感应外部噪音，并向本机发送相等且相反的消除信号。降噪效果在非常安静的环境下可能不明显，或可能会听到一些噪音。视佩戴方式而定，降噪效果可能有所不同。或可能发出嗡嗡声（振鸣），在此情况下请取下本机，然后重新佩戴。

电池注意事项

该设备可以内置数码充电锂电池供电。
第一次使用前，请至少检查设备充电8小时

- 充电电池只能在成人监督下进行充电。
- 只能使用附带的 Micro USB 电缆和电池充电。
  不正确的充电可能会损坏电池和设备。
- 请勿试图打开可充电电池或电池组。拆卸固定有可用的零件。
- 若电池放在儿童不能接触的地方。如果吞咽，请马上到医院治疗。
- 请勿将电池丢入火中。否则可能会发生爆炸。
  电池如果损坏可能包含爆炸，请根据当地情况处理规定。

产品参数

负载阻抗：32Ω	电池容量：750mAh
S/N：2-105dB	使用时间：40小时蓝牙,不开降噪) 20小时蓝牙,开降噪)
频率范围：20Hz-20KHz	充电：5小时(蓝牙,不开降噪)
支持：蓝牙 Line in	35小时(蓝牙,开降噪)
降噪最大深度：-35dB	

*以上数据全部来自实验室，仅供参考。

— 1 —

功能键指示



充电

在使用过程中，若看到仅红灯闪烁时，表示耳机电量过低。
请您充电后使用。
红灯闪烁＝正在充电　　蓝灯常亮＝已充满电
充电时间　约2小时

警告：本产品的可充电电池必须妥善处置，以使回收利用。墨水-墨烯电池放入火中，以免引起爆炸。

开关机

功能	操作	指示灯
开机	长按多功能键约3秒	蓝灯亮1秒
关机	长按多功能键约3秒	蓝灯亮1秒
降噪打开	按动降噪开关至ON状态	绿灯常亮
降噪关闭	按动降噪开关至OFF状态	绿灯熄灭

— 2 —

蓝牙配对连接

1.按圆知下操作使耳机进入配对模式:

功能	操作	指示灯
进入配对模式	开机未连接状态下:长按多功能键5秒 关机状态下:长按多功能键7秒	红蓝灯闪烁

2.开启手机蓝牙，搜索蓝牙设备，选择 EB-850ANC 配对连接，成功后提示音响起，蓝色指示灯熄灭。

注意：
- 配对状态下，2分钟未连接或功放进入配对模式，超时之后5分钟未连接，耳机自动关机。
- 若手机显示输入配对密码，请输入"0000"。
- 完成配对后，耳机和手机会有互动提示，下次使用时，耳机会自动连接最近一次连过的设备。

— 3 —

功能操作

功能	耳机状态	操作
接听来电	来电响铃	短按多功能键
拒绝来电	来电响铃	长按多功能键2秒
挂断来电	通话中	短按多功能键
唤醒语音助手	已连接设备	三击多功能键
关闭语音助手	关闭语音助手	三击多功能键
增加音量	播放音乐	短按 + 键
减少音量	播放音乐	短按 - 键
上一曲	播放音乐	长按 - 键
下一曲	播放音乐	长按 + 键
暂停播放	暂停播放	短按多功能键一次
恢复播放	播放音乐	短按多功能键一次

注意：
*当耳机音量调至最大时，若会听到本机音甲的提示音。

— 4 —

Line in音频模式

该耳机支持Line in音频输入，使用3.5 – 3.5音频线将耳机与音乐播放器连接，即可以有线收听音乐。

在Line in 音频线连接状态下可以开启降噪功能

注意:
请使用3.5mm音频线时，耳机处于关机状态，操作按键无功能。

外接设备



— 5 —

帮助

手机无法搜索到蓝牙耳机
可能原因： 蓝牙耳机不在开机情况或状态
解决方法： 长按耳机开关键，耳机响起开机进入少了耳机的互相配对状态，并完成配对
耳机只能顺利电话或只顺听歌
可能原因： 耳机没有按通话或音乐机程序指令
解决方法： 1. 关闭蓝牙耳机，再重新开启；
2. 关闭手机蓝牙，再重新打开；
3. 手机重启后，将手机蓝牙存储的所有配对资料清除，再重新进行配对连接。
耳机没有声音
可能原因： 1. 蓝牙耳机音量或手机音量处于最低状态
2. 蓝牙耳机与手机连接异常
3. 蓝牙耳机不在有效工作范围之内
解决方法： 1. 请将手机上的媒体音量
2. 蓝牙耳机和手机重新配对
3. 保持耳机位于手机10米范围内使用，且中间无贯穿障碍物
声音效果不好
可能原因： 手机信号差
解决方法： 换地区再尝试使用
充电灯不亮
可能原因： 1. 长时间未使用
2. 耳机开启或耳机触点没接触到
解决方法： 需要连上充电器及电源大约30分钟，灯才会亮
2. 重新摆放耳机至充电点触盖

— 6 —

保养与维护

在使用时，请阅读以下建议有助于您享受可保修条款，并延长产品的使用寿命。

- 保持产品干燥。勿将放在潮湿的地方，以免影响产品内部电路。需避免在潮湿或动或出汗较多时使用本产品，防止汗水渗透到产品内部损坏产品。
- 勿将产品放置在太阳晒射或者温度高的地方。高温会缩短电子部件的使用寿命，损坏电池，使某些塑料部件变形。
- 勿将产品放在过冷的地方，以免损坏内部电路板。
- 勿试图拆开产品。如果非专业人员，可能会损坏产品。
- 不要跌落，强烈振动，用硬块撞击产品，以免会损坏内部电路。
- 勿使用具有化学制品，清洁剂清洁设备。
- 不要用尖锐物品产品表面上戳刮，以免损坏外壳和影响外观。
  如果产品不能正常工作，请将其送至您的合格维修机构，工作人员会负责检查解决问题的。

保修条例

本产品有效保修期为自出售之日起一年内。在保修期限内正常使用维护的情况下，机器本身和外材料及功能出问题，发生故障，经查属实，本公司将提供免费维修及更换零件。

本产品的保修不适用于:

A. 耳机已超出保修期;
B. 用户没有按说明书要求，造成耳机折断，外壳破损;
C. 未经本公司授权自行拆装，修理，改动结构;
D. 无法提供保修卡及购票凭证;

— 7 —

E. 因自然灾害等不可抗力（如地震、火灾）原因造成的产品故障或损害;
注:保修服务不包含产品运输费用及在不能执上门维修服务

▲ 本保修条款解释权归本所有

保修反馈表(勾选)

A. 耳机无声音　B. 音质变差　C. 按键无法操作
D.无法配对设备　E.无法充电
F.其他

用户购买时间

购买的经销商

问题出现时间

用户联系方式

— 8 —

Alwa Electronics Int'l Co., Ltd.
Explore more at www.int-aiwa.com

Japan aiwa

EB-850ANC
True Wireless Earphones

Designed in Japan
アイワ株式会社

What is noise reduction?

The noise reduction circuit actually senses external noise through the built-in microphone and sends an equal and opposite noise cancellation signal to the unit.
The noise reduction effect may not be noticeable in very quiet environments or some noises may be heard.
Depending on how you wear it, the noise reduction effect may vary, or you may hear a hiss (squeaking), if you choose remove the unit and then wear it again.

Points for Attention On Battery

The device can be powered by a built-in rechargeable lithium battery. Charge the device for at least 8 hours before first-time use.
●Rechargeable batteries cannot only be recharged under adult supervision。
●Only the attached Type-C cable can be used to charge the battery. Wireless charging is also not available. Incorrect charging can damage batteries and equipment.
●Do not attempt to open rechargeable batteries or battery packs. There are no usable parts inside.
●Keep the battery out of reach of children. If children swallowed it, please take them to the hospital immediately.
●Do not throw the battery into the fire, otherwise it may explode. Batteries may also explode if being damaged, please handle and dispose it according to local conditions and regulations.

— 1 —

Product Parameter

Load impedance: 32Ω
S/N: >105dB
Frequency range: 20Hz-20KHz
Support: Bluetooth, Line in
Maximum noise deduction: >-35dB

Battery Capacity: 750mAh
Play Time: 40h (turn off bluetooth, active noise reduction)
20h (turn on bluetooth, active noise reduction)
35h (turn off bluetooth, turn off noise reduction)

*The above data are all from the laboratory and for reference only.

Indications of Function Keys



Recharge

During the use, only the red light flashing indicates that the headset battery is too low, please use it after charging.
Red light flashing = charging. Blue light on = fully charged.
Charging time: about 2 hours
Warning: the rechargeable battery of this product must be 回收 for proper recycling. Please do not put the battery into the fire so as to avoid explosion.

— 2 —

Turn on/ Turn off

Function	Operation	Indicator light
Turn on	Touch & hold the multifunction button for about 3 seconds	The blue light is on for 1 second
Turn off	Touch & hold the multifunction button for about 3 seconds	The blue light is on for 1 second
Open noise reduction	Turn the noise reduction switch to the ON status	The green light is constantly on
Close noise reduction	Turn the noise reduction switch to the OFF status	The green light is off

Bluetooth pairing connection

1.Make the headset enter into pairing mode according to following operations;

Function	Operation	Indicator light
Enter into pairing mode	Touch & hold the multifunction buttonfor 5 seconds when the headset is on; Touch & hold the multifunction button for 7 seconds when the headset is off	Alternating flashes of red and blue

— 3 —

2.Open cell phone Bluetooth and search for Bluetooth devices. Choose the EB-850ANC pairing connection. The prompt tone will be heard after successful connection, and the blue light will flash slowly.



Note:
- Under pairing connection state, the pairing mode will be closed if the connection fails after 2 minutes. The headset will be automatically turned off 5 minutes after connection fails.
- If the mobile phone requires the matching password, please enter "0000".
- Once the pairing is complete, the headset and phone will remember each other, and the next time they are used, the headset will automatically connect to the last connected device.

Function

Function	Headset status	Operation
Answering calls	Telephone ring	Short press the multifunction button
Refuse calls	Telephone ring	Tough & hold the multifunction button for 2 seconds
Hang up calls	Talking	Short press the multifunction button
Wake up voice assistant	Connected to device	Click multifunction keys for 3 times
Close voice assistant	Close voice assistant	Click multifunction keys for 3 times

— 4 —

Function	Headset status	Operation
Increase the volume	Play music	Short press + key
Reduce the volume	Play music	Short press - key
Last tune	Play music	Long press - key
Next tune	Play music	Long press + key
Pause	Stop playing music	Short press multifunction key for 1 time
Resume play	Play music	Short press multifunction key for 1 time

Note:
*When the volume of the headset is turned up to the maximum, you will hear the tone prompt sound.

Line in audio mode

The headset supports Line in audio input, and can be connected to the music player with a 3.5–3.5 audio cable, that is, you may listen to music with the wired earphone cable.
The noise reduction function can be turned on when the audio Line in is connected.
Note: when using the 3.5mm audio cable, if the headset is turned off, the operation buttons would have no function.

External Device Connection



— 5 —

INSTRUCTIONS

The mobile phone cannot search for Bluetooth earbuds
The Possible Reason. Bluetooth earbuds is not ready to be searched
Solution: Remove the earbudsfrom the charging Case, the earphones automatically turns on, Earphones have an audible prompt. Enter the mutual pairing status of 2 earphones.
Earbuds can only answer calls or only listen to songs
The Possible Reason. program error for earbuds or program error for mobile phone
Solution: 1. Turn off the Blue,with earbuds and restart
2. Turn off the phone Bluetooth and then turn it back on;
3. After the phone restarts, to delete all pairing dates which stored in the Bluetooth phone, and then re-pairing the connection.
No sound from earbuds
The Possible Reason. 1. Bluetooth earbuds volume or phone volume is at its lowest state
2. Bluetooth earbuds and mobile phone connection is abnormal
3. Bluetooth earbuds is not within the valided working range
Solution: 1. Adjust the media volume on your phone
2. Bluetooth earbuds and phone re-pairing
3. Keep the earphones within 10 meters of the mobile phone without any obstacle in the middle.
Sound is not good
The Possible Reason. The mobile phone's signal is weak
Solution: Change the area and try again
Charging light doesn't shine
The Possible Reasons. 1. Not used for a long time
2. The earbuds are reversed or the headphone contacts are not touched.
Solution: 1. You need to connect the charger to charge for about 30 minutes, the light will be on.
2. Reposition the earbuds to the charging

— 6 —

MAINTENANCE

Please read the following suggestions to help you comply with the warranty and extend the life of the product.
- Keep the product dry and do not place it in a damp place, soas not to affect the internal circuit of the product. It is necessary to avoid using this product during intense exercise or sweating to prevent sweat from penetrating into the product and damaging the product.
- Do not place the product in a place exposed to the sun or high temperatures. High temperatures can shorten the life of electronic components, damage batteries, and deform some plastic parts.
- Do not place the product in a cold place to avoid damaging the internal circuit board.
- Do not attempt to disassemble the product. If you aren'ot a professional, you may damage the product.
- Do not drop, strongly vibrate, or hit the product with hardware to avoid damaging internal circuits.
- Do not use harsh chemicals or detergents to clean the headphones.
- Do not use sharp objects on the surface of the product to avoid damage to the outer casing and affect the appearance.
  If the product does not work properly, please send it to your qualified service facility and the staff will be happy to help you solve the problem

WARRANTY

This product is covered under warranty for a period of one year from the date of sale limited to normal use and maintenance of the machine parts, materials and functions Problems and failures verified upon further identification will be provided free repair and replacement parts.

— 7 —

THIS WARRANTY DOES NOT APPLY:

(a) to a product that is out of warranty;
(b) to damage caused by operating the product outside the permitted or intended uses described by REMAX;
(c) to a product that has been disassembled, repaired or refitted without the authorization of REMAX;
(d) if warranty card and proof of purchase cannot be presented,
(e) to damage caused by earthquake, fire or other external causes, natural disasters, etc.

Note: The warranty does not include product transport costs and does not provide on-site maintenance services

▲ AIWA reserves all rights to clearly the warranty interpretation.

WARRANTY FEEDBACK FORM(TICK OFF)

A. No sound　B. Sound quality deteriorates
C. Button mal-function　D. Unable to pair other device
E. Can not recharge
F. others

Buying time

Dealers of sale

Time of problems

User's contact info

— 8 —

Alwa Electronics Int'l Co., Ltd.
Explore more at www.int-aiwa.com

Japan aiwa

EB-850ANC
真のワイヤレスブルートゥースイヤホン

Designed in Japan
アイワ株式会社

ノイズリダクションとは

ノイズリダクション回路は、内蔵マイクを介して実際に外部ノイズを感知し、このユニットに反対の周波数信号を送信します。非常に静かな環境ではノイズ低減効果が見えたない場合があります。装着方法によってはノイズリダクション効果が異なる場合や、ブーンという音（ハイブレーション）が出る場合があります。その際、取り外して再度装着してください。

バッテリー注意事項

この装置は内蔵の充電可能なリチウム電池で電力を供給できます。初めて使う前に、少なくとも8時間充電してください。
●充電バッテリーは大人の監督の下でのみ充電できます。
●バッテリーを交換するにはお届のMicro USBケーブル使用のみです。正しくない充電はバッテリーと設備を損傷する恐れがあります。
●バッテリーやバッテリーのセットを開けてみないでください。その中には使える部品がありません。
●バッテリーは子供が触れないところに置いてください。飲み込んだら、すぐに病院へ治療してください。
●バッテリーを火の中に入れないでください。爆発する恐れがあります。破損しても爆発する恐れがあります。現地の規定によって処理してください。

製品仕様

負荷インピーダンス：32Ω
S/N：>105dB
周波数範囲：20Hz-20KHz
サポート：ブルートゥース Line in
ノイズ低減最小深度：>-35dB

バッテリー容量：750mAh
使用時間：40小時(bluetooth オフ)(ノイズ低減オンにします)
20小時(bluetooth オン)(ノイズ低減オンにします)
35小時(bluetooth オフ)(ノイズ低減オフにします)

*以上のデータは実験室内測定値です。ご参考ください。

— 1 —

機能ボタンとインジケーター



充電

使用中、赤のインジケーター点灯が点滅していると、ヘッドホンのバッテリー残量が低いことです。充電してから使ってください。
赤のインジケーター点滅＝充電中
青のインジケーター点灯＝充電完了
充電時間：約2時間
警告：本製品の交換バッテリーは適切に処理。リサイクルするために、爆発を起こさないよう火で電池を大気に入れないでください。

電源オン/オフ

機能	操作	インジケーター
電源オン	多機能ボタンを約3秒長押し	青が1秒点灯
電源オフ	多機能ボタンを約3秒長押し	青が1秒点灯
ノイズリダクション	ノイズリダクションスイッチ/ボタンを短押し	緑が点灯
ノイズリダクションオフ	ノイズリダクションスイッチ/ボタンを短押し	緑が消灯

— 2 —

Bluetoothペアリング接続

1.次の操作に従ってヘッドセットのペアリングモードに入ります。

ペアリングモードに入り	電源オンで接続していない状態:多機能ボタンを5秒長押し 電源オフの状態:多機能ボタン7秒長押し	赤と青が交互に点滅

2.携帯のBluetoothを開いて、Bluetooth設備を検索する。
<B>-850ANCをペアリングと接続し、成功したら音が鳴り始めます。青のランプはゆっくりと点滅します。

注意:
●ペアリングの間で、2分間接続せずにペアリングモードを終了します。その後5分間も接続しない場合、ヘッドセットは自動的にオフになります。
●スマートフォンに「ペアのないヘッドホン」と表示されたら、「0000」を入力します。
●ペアリングが完了すると、ヘッドセットとスマートフォンは互いに記憶が残っています。今後使う時、ヘッドセットは最近接続した設備に自動的に接続されます。

— 3 —

機能操作

機能	操作	インジケーター
電話に出る	呼び出し音	多機能ボタンを押し
電話拒否	呼び出し音	多機能ボタンを2秒長押し
電話を切断	通話中	多機能ボタンを押し
音声アシスタントを起動	デバイスに接続済み	多機能ボタンを3回押し
音声アシスタントオフ	音声アシスタントオフ	多機能ボタンを3回押し
音量＋	音楽再生	+ボタンを押し
音量－	音楽再生	-ボタンを押し
前の曲	音楽再生	-ボタンを長押し
次の曲	音楽再生	+ボタンを長押し
一時停止	一時停止	多機能ボタンを1回押し
再び再生	音楽再生	多機能ボタンを1回押し

注意:
*ヘッドセットの音量が最大にすると、本機の音声提示が聞こえます。

— 4 —

Line inオーディオモード

本ヘッドセットはLINEのオーディオ入力を対応しています。3.5-3.5のオーディオコードを使ってヘッドセットを音楽プレーヤーに接続して、有線で音楽を聴くことができます。
Line inオーディオコード（付属以外）でノイズリダクションをオンすることができます。
注意:
3.5 mmオーディオコードを使用すると、ヘッドセットがオフになり、操作ボタンが機能しません。

外付け設備



— 5 —

ヘルプ

スマートフォンはイヤホンのBluetoothの検索できない場合
考えられる原因: Hu_をイヤホンは電源ONの状態にされていないかも。
解決策: 充電ケースからイヤホンを取り出し、イヤホンは自動的に電源ONにしてペアリングします。
イヤホンは電話と音楽の両方を聞くしかできません。
考えられる原因: イヤホンはスマートフォンのプログラムエラー
解決策: 1. イヤホンを、お電源がオフにした後、電源ONにします。
2. スマートフォンのBluetoothを一度OFFにした後、ONにします。
3. スマートフォンを再起動して、スマートフォンのBluetoothペアリング履歴を削除してからペアリングを行ってください。
イヤホンの音が出ない場合
考えられる原因: イヤホンは、音量低いはスマートフォンの音量はOFFに対応になっています。
2. イヤホンとスマートフォンの接続は異常になっています。
3. Hu_をイヤホンは有効の範囲外の場合、イヤホンは一つ
解決策: 1. スマートフォンのメディア音量を調整します。
2. イヤホンとスマートフォンを再度ペアリングします。
3. イヤホンとスマートフォンの距離を調整後等なしで10m以内に維持します。
音質が悪くない場合
考えられる原因: スマートフォンの電波が悪い
解決策: 場所を変えて試します。
充電時のインジケー。タ。が点灯しない場合
考えられる原因: 長時間に未使用
2. イヤホンを完全に入れたり、接触先に接触していません。
解決策: 1. 充電器につながって約30分の充電後、のインジケーターが点灯します。
2. イヤホンを充電ケ。スに入れ直します。

— 6 —

お手入れ方法

製品を使用する時、下記のおすすめを読めば、製品保証を保ちこたえます。製品を長持ちさせることができます。
- 製品の内部回路に影響しないため、製品の乾燥を維持し、濡れたままにしないでください。濡れ、湿度が汗が多くでる時に製品を使用することを避け、汗が製品内部に浸透し、故障の原因になります。
- 製品を直射日光や温度の高いところに置かないでください。高温になると電子部品の寿命が短くなり、電池が膨れたり、プラスチック部品が変形したりします。
- 製品を清浄剤の場所に置かないでください。内部回路基板の故障原因となります。
- 製品を分解しようとしないでください。専門職でないと、製品を壊す恐れがあります。
- 落下しないでください。強く振動して、硬い物で製品に衝突して、内部の電気回路が壊れる原因になります。
- 強い化学製品、洗剤を使ってイヤホンを掃除しないでください。
- 尖ったもので製品の表面に傷をつけないでください。外装を破損し、外観にも影響を与えて、しまいます。製品がうまく動作しない場合は、合格保証機関に従ってください。スタッフが熱心に問題を解決してくれます。

保証規則

本製品の有効保証期間は発売日から一年間で、保証期間内に正常に使用し、メンテナンスしている場合、製品本体の部品と機能に問題、故障が発生した、ふは、法行の際ったを、事実であれば、無料で修理し、または部品を交換します。
下記の場合、本製品が保証できません。
A.イヤホンは保証期間を超過したこと;
B.ユーザーが取扱説明書に従わなくイヤホンが折れ、ケースが破損したこと;
C.当社の授権なしに、自分で分解、修理し、構造を変更すること;
D.保証書及び購入証明の提供ができないこと。

— 7 —

E.自然災害などの不可抗力（例え地震、火災）による製品の故障が生じたこと
注:保証サービスは製品の送料を含みません。出張修理は行っておりません。
⚠ 本保証書の解釈権はaiwaに属します

保証フィードバック表（チェック入れ）

A.音声なし　B.音質が悪くなった　C.ボタンの操作ができない
D.ペアリングできない　E.充電できない
F.その他

ご購入時間

ご購入先

問題があった時期

ご連絡方法

— 8 —

Alwa Electronics Int'l Co., Ltd.
Explore more at www.int-aiwa.com