

# MI-X175 Retro Heritage Lite

User Manual

# **Safety Cautions**

- 2. Do NOT attempt to disassemble or alter the device.
- 3. Do NOT expose device to excessive heat (Direct sunlight etc.).

# **Important Safety Instructions**

- 1. Please do not place device near any form of heat sources.
- 2. Please use the accessories specified by the manufacturer.
- 3. Please refer all servicing/repairs to a qualified personnel should there by any form of damage to the device.
- 4. Keep this user manual for future referencing/troubleshooting.
- Please heed ALL safety cautions.

- 1. Always keep device AWAY from fire and heat sources.
- 4. Do NOT immerse device into any form of liquids.

# Unboxing

- MI-X 175 Retro Heritage Lite
- Type-C Charging Cable
- 3.5mm AUX Cable
- Handle
- User Manual

Please refrain from using any damaged components. Contact your local authorized AIWA distributor/customer service should you need any assistance.

### **Product Specifications**

Model Number: MI-X 175 Retro Heritage Lite

BT Version: V5.0

Power Output: 20W X 2

Driver: 3inch \*2+2inch \*2

Frequency Response: 120Hz~20kHz

S/N Ratio: 60dB

Supported Profiles: WMA, MP3, FLAC, MAV

Transmission Distance (Estimated): 10 Meters (No Obstacles)

DC Input Voltage/Current: DC 5V/ 2A (Type-C)

Battery: 7.4V/4000mAh (Li-on)

Playback Time: 9-11 Hours (50% Volume): 3-4 Hours (100% Volume)


Charging Time: 9-10Hours

Dimensions: 252\*160\*142mm

Weight: 3.1KG


The above playback & charging times are estimated values tested in a practical environment and may vary upon individual usage habits.

#### **Product Overview**



- Power ON/OFF
- 2. Function LED Indicator Light
- Charging LED Indicator Light
- Previous Track
- Play/Pause (Click once) / Switch Modes (Press and hold) / Call Control (Click once to Answer & End Call, Press and hold to Reject Call).
- 6. Next Track / Disconnect BT (Press and hold)
- 7. Treble Tuning Knob
- Bass Tuning Knob
- 9. Volume Tuning Knob
- 10. USB Port
- 11. Charging Port (DC 5V)
- 12. AUX-In
- 13. Battery display
- Phone call

# **Connecting the Product**



- 1. Turn on Bluetooth (BT) on your mobile device.
- 2. Turn on the speaker.
- 3. Search and connect to "AIWA Retro Heritage Lite" from your mobile
- 4. Press and hold the "PAIR" button to disconnect BT.

MI-X175 Retro Heritage Lite automatically reconnects to the last paired mobile device it was

# TWS Function

Synced audio playback from two (2) speakers for true wireless stereo experience. (Only compatible with the same speaker model: MI-X175 Retro Heritage Lite)

- 1. Turn on both speakers.
- 2. Press and hold on BOTH speakers until a notification prompt beep is heard.
- 3. TWS (True Wireless Stereo) playback is now available.
- 4. Connect to ONE (1) of the speakers via BT Connection.
- 5. Long press (4 to exit TWS mode.

## Listening to music from external audio source

#### USB Playback

Insert USB Disk into the designated port.

#### AUX-IN

Connect speaker and Audio source via a 3.5mm AUX Cable.

Press and hold M/ II button to switch between different audio sources

#### Battery & Charging

Connect charging cable to the speaker and a suitable power source.

Approximate Charging Time: 9-10 Hours

Please charge up the speaker fully prior to first-time usage.

MI-X175 Retro Heritage Lite will enter power-saving mode after 15 minutes of inactivity. Long press "MODE" button for 3 seconds to exit power-saving mode.



Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com