

Important Safety Instructions

Please do not use device near any form of heat sources. Please use accessories specified by the manufacturer. Please refer all servicing to qualified personnel should there be any form of damage to the device. Keep this user manual for future reference/ troubleshooting. Please heed ALL safety cautions.

Safety cautions

Keep device AWAY from fire and heat sources at all times. Do NOT attempt to disassemble or alter the device. Do NOT expose the device to excessive heat. (Direct sunlight e.g.). Do NOT immerse/ expose device to any form of fluids.


Warning

Using earphones at moderate to high volumes for extended periods of time will result in permanent hearing damage. We recommend that you keep media playback volume level from low to moderate at all times. Please do not use earphones while performing activities that require hearing surrounding noises/ sounds. (Driving, Cycling, jogging etc.)

Unboxing




AT-X80S



Charging Case



Silicone Ear-tips



USB Charging Cable

* Please refrain from using any damaged components. Contact your local authorised aiwa distributor/customer service. *

Device Power On / Off



- Auto Power On** Remove Earbuds from charging case.
- Auto Power Off** Place Earbuds back into charging case.
- Manual Power On/Off** Press and hold button on both earbuds for 3 seconds.

* Charging case has to be charged for earbuds automatic power up sequence. *
* Make sure devices are within Bluetooth working distance (within 10 metres) *

Earbuds Syncing - Left & Right



- Power up Earbuds.
- The earbuds will sync with each other automatically (Prompt sound "Double Beep").

* Troubleshooting: When earbuds are unable to sync with each other, power off both earbuds, then hold both L& R buttons down for approximately 10 seconds to restore to original settings. *

* Alternating Red & Blue lights indicates earbuds are being restored to original settings. *

Earbuds Pairing With Device



- Power up Earbuds.
- The earbuds will sync with each other automatically
- Connect to "AT-X80S" from your smartphone/tablet's Bluetooth list.

* Flashing blue lights indicates successful connection. *

* Make sure there's only one device connecting at the same time. *

* Make sure devices are within Bluetooth working distance (within 10 metres) *

Device Control



- For calls**
- Answer call: Press either L/R once.
 - End current call: Press either L/R once.
 - Reject call: Double press either L/R.

Music - Single side usage

- Play/Pause: Press either L/R once.
- Next Track: Double Press R.
- Previous Track: Double Press L.

Siri/Google Assistant

Long press L/ R for approximately 1.5s to activate Siri/Google assistant.

* Not all devices support this functionality. *

Charging & Battery

Low Battery Alert


Red Light flashes when earbuds power is >20%. Earbuds will auto power off upon running out of battery power.

Charging the Earbuds

Insert USB charging cable into charging port on the charging case.

* Charging case holds up to approximately 15 Hours music playback time. *

Selecting Ear-tips



Select ear-tips base on the below criteria:

- Fits and form a perfect seal within the ear canal
- Does not fall out easily
- Comfortable fit

* Forming the perfect seal is essential for the ATX-80S to deliver maximum audio performance. *

Troubleshooting

I can't find "ATX-80S" on my bluetooth device's list/ unstable connection.

- Make sure "ATX-80S" and your device are within Bluetooth working distance.
- Make sure "ATX-80S" is charged and has enough power.
- Perform a factory reset and re-attempt to pair again.

Disconnection occured within Bluetooth working distance.

Please make sure there are no metals or other materials within a relatively close range which will interfere with the Bluetooth connection.

* Please refrain from using any damaged components. Contact your local authorised aiwa distributor/customer service. *

Customer service

For more product information please visit www.int-aiwa.com.

Contact your local authorised dealer/ customer service. Refer to the warranty label provided in the box.

Limited Warranty

Please refer to the warranty label provided in the box.

Note: Disassembling device voids warranty.
Note: Liquid submersion voids warranty.

Device Specifications

Bluetooth Version -----	V5.0
Bluetooth Distance -----	10-15M
Earbuds Battery -----	50mAh*2
Charging Case Battery -----	350mAh
Charging Time -----	About 1.5 hours
Music Playing Time -----	About 5 hours
Calling Talk Time -----	About 4 hours
Standby Time -----	200 hours