

SB-X150 II

User Manual



Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Unboxing



SB-X150 II



Type-C charging cable






3 5mm line-in AUX cable User Manual

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Product Overview



- 1. Battery life indicator light
- 2. Volume+/Next track
- 3. Volume-/Previous track
- 4. Play/Pause/TWS connection/BT Disconnection
- 5. Hands-Free calling
- 6. Mode
- 7. Power button
- 8. Status indicator light
- 9. Reset button
- 10. USB driver slot
- 11. AUX in slot
- 12. Type-C charging port
- 13. Built-in microphone

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Power ON/OFF

Hold down power button (a) for 3 seconds.

Switching playback modes

Short press mode button (18) to switch between BT-AUX-USB mode.

TWS Connection/ BT Disconnection

Double press () to initiate TWS connection. Long press (x) to disconnect BT connection.

Volume +/-, Next/Previous Track


Long press — & + button to decrease & increase audio volume respectively. Short press \bigcirc & + to trigger previous & next track respectively.

USB driver playback

Insert the USB driver(Audio prompt accompanied by Orange indicator light indicates successful connection). Playback will start immediately

AUX Line-in Playback

Power up the speaker, insert 3.5mm audio cable. (White indicator light indicates successful connection).




Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

BT Connection

1. Power on SB-X150 II.

2. Find "SB-X150 II" in your mobile BT devices list and connect.






Battery & Charging

Connect Micro-USB charging cable to any power source and to SB-X150 II

Supports 5V,9V,15V,20V quick charging. Maximum quick charging output: 40 W *Charging time:3-5hours*




TWS (True Wireless Stereo) Playback

Double press TWS button on both devices simultaneously to establish TWS

(Product is compatible with our SB-X Range 100/120/150 II. Please refer to www.int-aiwa.com for more updated information regarding our product line up.)

Perform BT connection (refer to BT Connection) with host unit only (Flashing Indicator Lights)



TWS (True Wireless Stereo) Disconnection

Long press TWS button to stop TWS connection.

Connect to 2 devices

The SB-X150 II can connect up to 2 devices.

Perform BT connection twice sequentially (refer to BT Connection) with the speaker unit.

SB-X150 II will prioritize the first connected device's playback. Pausing of the first device playback is necessary for secondary device playback.

LED Indicator light

Flash quickly BT ready to pair BT mode: Flash slowly BT connected successfully

Stay on Flash White AUX mode: Stay on Playing music Slowly Pause **AUX IN Playing**

Flash slowly Orange USB mode: Stay on USB Play

Flash slowly Pause

Low battery:

Audio prompt "Beep" will be played. Speaker will shutdown after 3 prompts.

Specification

Item:Wireless Portable Speaker	Model name:SB-X150 II
Rated Voltage:DC5V	BT version:5.0
Rated input current:1A	Support Audio format:aptX/SBC/AAC/MP3
BT working rang:20M	Battery:18650/2000mah*4
Mid&high driver output:10W*2	Bass driver output:20W
Play time:6-8Hours	Charging time:3~5Hours
Dimension:230*125*60mm	Weight:1122g



Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com