

aiwa

Adventure Mini IP67 | SB-X80

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

User Manual
使用者指南
使用手説明書
उपभोक्तागाइड
사용자 설명서
คู่มือการใช้
hướng dẫn sử dụng
प्रयोगकर्ता पुस्तिका

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Important Safety Instructions


1. Please do not install device near any form of heat sources.
2. Please use accessories specified by the manufacturer.
3. Please refer all servicing to qualified personnel should there be any form of damage to the device.
4. Keep this user manual for future reference/ troubleshooting.
5. Please heed ALL safety cautions.

SAFETY CAUTIONS


1. Keep device AWAY from fire and heat sources at all times.
2. Do NOT attempt to disassemble or alter the device.
3. Do NOT expose the device to excessive heat. (Direct sunlight e.g.).
4. Product label is located at the bottom of the product.

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Unboxing



SB-X80



Micro USB charging cable





AUX Cable

Please refrain from using any damaged components.
Contact your local authorised aiwa distributor/customer service

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved


Device Overview



1. Power button
2. Play/ Pause/ TWS Connection/ Disconnection
3. Volume -/ Previous song (Short press)
4. Volume +/ Next song (Short press)
5. Microphone
6. Charging indicator
7. Micro USB charging port
8. Reset button
9. AUX - In Part

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved



Device Walkthrough - Power ON / OFF



Hold power button ⑤ for 3 seconds.
(Refer to device overview page)

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Device Walkthrough - Connection




1. Power on SB-X80.
2. Find "SB-X80" in your mobile devices list and connect.
3. Long press play/pause button (Refer to device overview page) to terminate connection.

Make sure there's only one device connecting at the same time
Make sure devices are within working distance (within 10 metres)
Use mode button to interchange playback mode (as in this order)

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Device Walkthrough - AUX Connection




1. Power on SB-X80.
2. Connect 3.5mm AUX cable.

Use mode button to interchange playback mode (as in this order).

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved


Device Walkthrough - Answering Calls



Short press - Play/Pause button to answer an incoming call.
Long press - Play/Pause button calls button to reject an incoming call.
Short press - Play/Pause button calls button to end an ongoing call.

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Device Walkthrough - True Wireless Stereo



Perform bluetooth connection (Refer to Device Walkthrough - Bluetooth Connection) with the selected host speaker unit (Choose any 1 between the 2).

Double press dedicated TWS function button on the host speaker unit to enter TWS pairing mode.
(Refer to Device Overview)

Long press dedicated TWS function button to exit TWS mode.


Turn on the other speaker unit, TWS connection will start automatically (Make sure both units are in close proximity).

TWS pairing mode lasts for 80 seconds only. Double pressing the dedicated TWS function button will have no effect within this period.

Speaker unit in TWS Mode > Power off > Power On > Speaker unit will remain in TWS Mode.

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Device Walkthrough - Battery & Charging




Connect Micro-USB charging cable to any power source and to SB-X80 as shown.

Charging time - Approx. **3 Hours**
Playback time - Approx. **10 Hours**

Low battery indicator - "Beep" sound every 15 seconds X 3 before device automatic shutdown

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Cleaning & maintenance



Wipe down SB-X80 with a soft dry cloth.

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Troubleshooting

I can't find "SB-X80" on my device's list/ unstable connection.

1. Make sure "SB-X80" and your device are within working distance.
2. Make sure SB-X80 is charged and has enough power.
3. Re-attempt to pair again.

Disconnection occurred within working distance.

1. Please make sure there are no metals or other materials within a relatively close range which will interfere with the connection.

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Customer service

For more product information please visit www.int-aiwa.com.

Contact your local authorised dealer/ customer service. Refer to the warranty label provided in the box.

Limited Warranty

Please refer to the warranty label provided in the box.

Note: Disassembling device voids warranty.

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Device specifications

Model - SB-X80

Rated power - 5W

Technology - V5.0

Bluetooth Profile - A2DP, HFP, HSP, AVRCP

Frequency response - 20Hz - 20KHz

THD - <1%

Connection Range - 20M

Battery Capacity - 1800mAh

Speaker Dimension - 85 x 85 x 46 mm

Weight - 215g

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

aiwa

Aiwa Electronics Int'l Co., Ltd.
Explore more at www.int-aiwa.com

aiwa

Adventure Mini IP67 | SB-X80

User Manual

使用者指南

使い手説明書

उपभोक्तागाइड

사용자 설명서

អ្នកប្រើប្រាស់

hướng dẫn sử dụng

प्रयोगकर्ता पुस्तिका

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

重要安全說明


1. 請不要將產品靠近任何形式的熱源。
2. 請使用原廠規格的配件。
3. 產品如果有任何故障，請交由合格的維修人員處理。
4. 請妥善保存此說明書以便日後參考。
5. 請注意所有的注意事項。

注意事項


1. 請保持產品遠離火源跟熱源。
2. 請勿嘗試拆解或改裝本產品。
3. 請勿將產品懸置在過多熱量的地方（如直射陽光...等等）。
4. 產品標籤張貼在產品底部。

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved


包裝內容



SB-X80



Micro USB 充電線




AUX音頻線


如果產品及配件有發生異常狀況，請聯絡當地 aiwa 授權經銷商或是客服中心

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

產品介紹



1 2 3 4




5 6 7 8

1. 電源鍵
2. 播放鍵/ 暫停鍵/ TWS 配對鍵/ 取消配對鍵
3. 減少音量/ 上一曲 (短按)
4. 增加音量/ 下一曲 (短按)
5. 麥克風
6. 充電指示燈
7. 充電線接口
8. 重置鍵
9. 音頻線接口

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved


產品操作 - 開 / 關機



按住電源鍵 3 秒來開 / 關機。
(請參考產品介紹圖)

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

產品操作 - 手機連接




1. 將 SB-X80 開機。
2. 在您手機的設備清單中找到 "SB-X80" 並選擇配對。
3. 長按播放鍵/ 暫停鍵 (請參考產品介紹圖) 來取消連接。

請確定時間內只有一支手機跟音響連接
請確認手機跟手機在有效距離內 (10米)
使用模式鍵來切換播放模式

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

產品操作 - 連接AUX音頻線




1. 將 SB-X80 開機
2. 接上 3.5mm AUX 音頻線

使用模式鍵來切換播放模式

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

產品操作 - 接聽來電




短按通話鍵接聽來電。

長按通話鍵拒接來電。

通話過程中再次短按通話鍵掛斷電話。

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

產品操作 - TWS真無線立體聲




1. 選擇其中一台音箱 (此為主機)，正常進行開機和藍牙連接。
2. 藍牙配對成功後，快速按兩下TWS配對鍵，主機會持續發出 (嘟嘟) 兩聲TWS配對提示音，進入TWS配對等候狀態。
3. 此時啟動另一台音箱 (副機)，開機後主副機會自動進行配對，配對成功後會發出配對成功提示音 (嘟嘟)。

請注意：

- A. TWS等待連接 80秒沒連接成功，自動退出TWS連接，音響回到原來的播放狀態。
- B. TWS連接狀態 80秒之內再次按兩下TWS配對鍵是沒有作用的。
- C. TWS連接成功後，長按副機播放/暫停鍵，斷開TWS連接，主機不斷開藍牙連接，重新開機後TWS不會回連。
- D. TWS連接成功後，長按主機播放/暫停鍵，斷開TWS連接，主機斷開藍牙連接，重新開機後TWS不會回連。
- E. 正常長按電源鍵開機後，重新開機TWS會自動回連。

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

產品操作 - 電池與充電




將內附的 Micro-USB 充電線插入充電口與 5V/1A 的電源供應器進行充電 (電源供應器請自行選購)

充電時間- 約 3 小時
播放時間- 約 10 小時

低電提醒 - 每隔15秒會發出"唧"聲警告音，連續 3 次後機器自動關機

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

清潔與維護



請用柔軟的乾布來擦拭 SB-X80

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

問題與解答

在手機設備清單上找不到 "SB-X80" 或是連接不穩定?

1. 請確認您的手機與 "SB-X80" 是在有效距離範圍內。
2. 請確認 SB-X80 擁有足夠的電力。
3. 將音箱重設回到出廠設定，再重新配對一次。

在設備有效距離內還是發生斷線現象?

1. 請確認有無金屬或是其他材料太過靠近造成設備連接的干擾。

客戶服務

有關產品的更多資訊，請參考我們網站 www.int-aiwa.com。

您可以參考內附的保卡，聯絡當地的 aiwa 授權經銷商或是客服中心。

產品保固

請參考包裝盒中提供的保固卡。

注意：拆卸設備不在保固範圍內

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

規格

商品名稱：便攜音箱

型號：SB-X80

喇叭功率：5W

技術版本：5.0

支援協定：A2DP, HFP, HSP, AVRCP

頻率範圍：20Hz - 20KHz

總協失真：≤1%

無線接收距離：20公尺

電池容量：1800mAh

額定輸入電流電壓：DC 5V/1A

尺寸：85 x 85 x 46 mm

重量：215 公克

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

限用物質含有情況標示聲明

限制物質名稱	鉛 (Pb)	汞 (Hg)	鎘 (Cd)	六價鉻 (Cr(VI))	多環芳烴 (PAHs)	鄰苯二噁英 (dioxin)
鉛 (Pb)	○	○	○	○	○	○
汞 (Hg)	○	○	○	○	○	○
鎘 (Cd)	○	○	○	○	○	○
六價鉻 (Cr(VI))	○	○	○	○	○	○
多環芳烴 (PAHs)	○	○	○	○	○	○
鄰苯二噁英 (dioxin)	○	○	○	○	○	○

備註 1: "超出 0.1 wt%" 及 "超出 0.01 wt%" 係指用物質之百分比含量超出百分之十及百分之一之限制數值。
備註 2: "○" 係指該限制物質之百分比含量未超出百分之十及百分之一之限制數值。
備註 3: "○" 係指該限制物質之百分比含量未超出百分之十及百分之一之限制數值。
備註 4: "○" 係指該限制物質之百分比含量未超出百分之十及百分之一之限制數值。

aiwa

Aiwa Electronics Int'l Co., Ltd.
Explore more at www.int-aiwa.com

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved